

16268

BLACK SPLIT TOP METAL MOUNT KIT FOR METAL ROOFS



A DIVISION OF QUICKSCREWS INTERNATIONAL CORP

INSTALL INSTRUCTIONS



RECOMMENDED MATERIALS

- Rafter locator
- Chalk or a crayon
- Drill with a 3/16" drill bit

INSTALLATION INSTRUCTIONS

1. Locate the rafter and predrill the hole
2. Place L-Foot over umbrella washer and drive until it compressed and L-Foot is secure