


16321

16322

2 1/4" EPDM CONDUIT MOUNT WITH SCREW FOR ASPHALT SHINGLE ROOFS



A DIVISION OF QUICKSCREWS INTERNATIONAL CORP

INSTALL INSTRUCTIONS



RECOMMENDED MATERIALS

- 3/8" Hex Driver

INSTALLATION INSTRUCTIONS

1. Insert the screw into the conduit clip and EPDM block
2. Drive until block is compressed



***Block and screw only.** Clip NOT included

