

# 17650

17651

## SOLARGRIPZ FOR STANDING SEAM ROOFS



A DIVISION OF QUICKSCREWS INTERNATIONAL CORP

# INSTALL INSTRUCTIONS



## RECOMMENDED MATERIALS

- No. 13 Wrench
- Hex Key (for 5/16" x 1-1/2" Hex Cap Screws)



## INSTALLATION INSTRUCTIONS

1. Place the SolarGripz according to the design of your array.
2. Tighten the SolarGripz.
3. Use the Hex Key & Wrench to secure the SolarGripz on to the roof.



## TORQUE REQUIREMENTS

5/16-18 Bolt requires 6 minimum torque ft-lb

