

17741

W-TILE REPLACEMENT FOR CURVED TILE ROOFS



A DIVISION OF QUICKSCREWS INTERNATIONAL CORP

INSTALL INSTRUCTIONS



RECOMMENDED MATERIALS

- Tin snips
- QuickBOLT mount

INSTALLATION INSTRUCTIONS

1. Remove tile
2. Install QuickBOLT mount
3. Snip tile replacement at hook edges
4. Place tile replacement